

- 3. Using a pencil, mark the back two holes through the side grommet holes.
- 4. Remove the unit, and confirm marks are in the correct location.
- 5. Mark a center point between the back two holes.
- 6. Drill 5 holes using the 1/8" drill bit.
- 7. Return the unit, and secure in place with screws (A and B).

- 4. Mark the bottom 2 holes with a pencil through the grommet holes.
- 5. Remove the unit, and confirm holes are in the correct location.
- 6. If mounting to drywall, drill holes with the 1/4" drill bit, and place anchors (C) in the holes.
- 7. If mounting to a stud, drill holes with 1/8" drill bit.
- 8. Return the unit to the location, and secure in place with screws (D).