

RECLAIM[®] ACRYLIC SNEEZE GUARD EXTRA LARGE CUBICLE WALL CLAMPS

Product Specifications

Item Number	DIVWT-CLAMPXL
Clamp Material	Powder-coated aluminum
Clamp Type	Hand-adjustable top clamp (tool free attachment to cubicle wall)
Total Clamp Adjustment Range	1.13" to 3.5"
Tool-Selectable Clamp Ranges (3):	1.13" to 2", 2" to 2.625", and 2.625" to 3.5"
Required Tools for Assembly	Allen wrenches (included) and Phillips screwdriver (not included)
Weights, Dimensions, What's Included	See chart below



Product #	Product Description	Product Height (each)	Product Width (each)	Product Depth (each)	Product Weight	# of Clamps	Shipping Method	Box Length	Box Width	Box Depth	Shipping Weight
DIVCL-2CLAMPXL	XL Cubicle Wall Clamps, 2-pack	4.41"	5.5" to 3.95"	1.87"	2.9 lbs.	2	Ground	13"	11"	2"	3 lbs.
DIVCL-3CLAMPXL	XL Cubicle Wall Clamps, 3-pack	4.41"	5.5" to 3.95"	1.87"	4.3 lbs.	3	Ground	13"	11"	2"	5 lbs.

To Order, Call Your
Sales Representative
or 800-323-4656

DIVWT – SPEC SHEET

Product #	Product Description	Height	Width	Panel Color	# of Clamps	Shipping Method	Box Length	Box Width	Box Height	Shipping Weight	Panel Weight		
DIVWT-2430C	24" x 30" Clear Acrylic Divider w/ 2 Divider Wall Top Clamps	30"	24"	Clear	2	Ground	33"	26"	2"	13 lbs.	6.1 lbs.		
DIVWT-3030C	30" x 30" Clear Acrylic Divider w/ 2 Divider Wall Top Clamps		30"				34"	32"	2"	15 lbs.	7.7 lbs.		
DIVWT-4830C	48" x 30" Clear Acrylic Divider w/ 2 Divider Wall Top Clamps		48"				52"	32"	2"	23 lbs.	12.2 lbs.		
DIVWT-6030C	60" x 30" Clear Acrylic Divider w/ 3 Divider Wall Top Clamps		60"		62"		32"	2"	29 lbs.	15.3 lbs.			
DIVWT-2424C	24" x 24" Clear Acrylic Divider w/ 2 Divider Wall Top Clamps	24"	24"		2		3	Ground	28"	26"	2"	11 lbs.	4.9 lbs.
DIVWT-3024C	30" x 24" Clear Acrylic Divider w/ 2 Divider Wall Top Clamps		30"						34"	26"	2"	13 lbs.	6.1 lbs.
DIVWT-4824C	48" x 24" Clear Acrylic Divider w/ 2 Divider Wall Top Clamps		48"						52"	26"	2"	19 lbs.	9.8 lbs.
DIVWT-6024C	60" x 24" Clear Acrylic Divider w/ 3 Divider Wall Top Clamps		60"						64"	26"	2"	24 lbs.	12.2 lbs.

IMPORTANT WARNINGS:

***Proper Care and Cleaning of Acrylic – PLEASE READ BEFORE INSTALLING:** Acrylic sheeting can be damaged by harsh solvents and cleaners. Only use cleaning products labeled “commercial plastic cleaners”, or mild soap and water to remove dirt and debris. When applying the cleaner, use a non-abrasive lint-free or microfiber cloth that won't scratch the surface. Never use products containing ammonia, acetone, carbon tetrachloride, scouring compounds, alcohol, bleach, aromatics, or gasoline. Chemical glass cleaners (even if they are environmentally friendly, organic, or non-scented) are also not to be used. All solvents need to be wiped clean with fresh water and blotted dry to reduce and prevent water spotting. Failure to adhere to the above guidelines can cause yellowing, cracks, and scratches in acrylic sheeting and may give the surface a frosted appearance. It will also void the Limited Warranty – our Limited Warranty does not apply to any damage caused by or the result of improper cleaning, handling, installation, operation, maintenance, pressure washing, accident, fire, natural disaster, explosion, abuse, vandalism, chlorine, chemicals from sprinkler systems, or other external forces. This warranty shall be null and void if any harmful solvents are used to clean.

****Use of Dry-Erase Markers:** Water-soluble dry-erase markers are safe for use on these acrylic panels. Other forms of dry-erase markers are not recommended because they will be difficult to erase and could possibly leave stains and ghosting.